




A 12

Stud Welding Gun
with shielding gas leg assembly PSS-2

93-20-274



Operating Manual



After-sales service for Germany:

HBS Bolzenschweiss-Systeme GmbH & Co. KG
Felix-Wankel-Strasse 18
85221 DACHAU
GERMANY

Phone **+49 8131 511-0**
Fax **+49 8131 511-100**
E-mail **international@hbs-info.com**
Web **www.hbs-info.com**

A 12 Operating Manual Issue 2021-01 Order No. E-BA 93-20-274

Translation of the Original Operating Manual

Please keep the manual in a safe place for future reference.

Transmission and duplication of this document, dissemination and notification of the contents are not permitted unless expressly approved.

All rights, errors and technical amendments reserved.

© HBS Bolzenschweiss-Systeme GmbH & Co. KG



Dear Customer,

Many thanks for buying a stud welding machine from HBS Bolzenschweiss-Systeme.

We at HBS wish you success at all times when working with this stud welding machine.

The high level of quality of our products is guaranteed by ongoing further development in the design, equipment and accessories. This may result in differences between the present operating manual and your product. No claims can therefore be derived from the data, illustrations and descriptions.

We have compiled the data and information in this reference work with the greatest care, and have made every effort to ensure that the information contained in this manual was correct and up-to-date at the time of delivery. We can nevertheless give no guarantee for an absolutely error-free document.

Should you discover any errors or unclear points when reading this operating manual, please do not hesitate to contact us.

We would also be grateful for any feedback should you have any suggestions or complaints to make about our product.

HBS Bolzenschweiss-Systeme GmbH & Co. KG
Felix-Wankel-Strasse 18
85221 Dachau
GERMANY



Table of Contents

1	Important Safety Precautions	6
2	Symbols and Terms Used	10
3	Scope of Supply	13
4	Accessories	13
5	Technical Data	14
6	Intended Use	16
7	Warranty	17
8	Design and Function	18
9	Welding Process	19
10	Preparing the Stud Welding Gun	20
10.1	Mounting the Chuck	22
10.2	Setting the Welding Parameters	23
	Adjusting Lift	25
	Adjusting Spring Force	26
	Setting the Insertion Depth (Protrusion)	27
11	Welding	28
12	Troubleshooting	29
13	Maintenance and Care	31
13.1	Cleaning	31
13.2	Inspection and Tests	32
13.3	Changing the Chuck	33



14	Storage	35
15	Disposal	35
	Declaration of Incorporation of partly completed Machinery	36
	Service & Support	37
	Index	38



1 Important Safety Precautions

The target group for this manual are qualified personnel who in view of their technical training, know-how and experience and knowledge of applicable regulations are able to assess the work assigned to them and recognise potential hazards.



Danger from incorrect use

- ◆ Use the stud welding machine only for the purpose described in this manual.

Otherwise you may endanger yourself or damage the stud welding machine.

You endanger yourself and others if you operate the stud welding machine incorrectly or fail to observe the safety precautions and warnings. This can lead to serious injury or extensive material damage.



Danger for unauthorised operating personnel

- ◆ Work with the stud welding machine only when
 - You are appropriately trained, instructed and authorised to do so, and
 - You have read and completely understood this operating manual.
- ◆ Never work with the stud welding machine when you are under the influence of
 - Alcohol,
 - Drugs or
 - Medication.



Danger from unauthorised modifications

- ◆ Never modify the stud welding machine or parts thereof without obtaining a clearance certificate from the manufacturer.

You will otherwise endanger yourself. This can lead to serious injury or extensive material damage.



Life-threatening danger for wearers of active implanted cardiac devices

Danger for workers at particular risk within the meaning of the EMF directive

Persons at particular risk within the meaning of the EMF directive are:

- Workers with active implanted medical devices
 - Workers with passive implanted medical devices that contain metal
 - Workers with medical devices worn on the body
 - Pregnant workers.
- ◆ Never operate the stud welding machine if you are among the group of workers at particular risk within the meaning of the EMF directive.
 - ◆ In this case, never remain in the vicinity of the stud welding machine during welding.
 - ◆ Never operate the stud welding machine if persons are located nearby who are among the group of workers at particular risk within the meaning of the EMF directive.


Strong electromagnetic fields are produced in the vicinity of the stud welding machine during welding. These fields can adversely affect the function of medical devices as well as the course of a pregnancy.



Danger from fumes and airborne particulates

- ◆ Switch on the welding fume extractor at the place of work.
- ◆ Ensure that the room is well ventilated.
- ◆ Never weld in rooms with a ceiling height of less than 3 m.
- ◆ Observe furthermore your working instructions and the accident prevention regulations.

This will help to avoid health damage due to fumes and airborne particulates.



Danger from glowing metal spatter (fire hazard)

Glowing hot weld spatter and liquid splashes, flashes of light and a loud bang > 90 dB (A) must be anticipated during stud welding.

- ◆ Inform colleagues working in the immediate vicinity accordingly before starting work.
- ◆ Ensure that an approved fire extinguisher is available at the workplace.
- ◆ Do not weld when wearing working clothes soiled with flammable substances such as oil, grease, petroleum, etc.
- ◆ Wear your proper protective clothing, such as:
 - Protective gloves in accordance with the relevant standard,
 - Non-flammable clothing,
 - A protective apron over your clothing,
 - Full-ear hearing protection in accordance with the relevant standard,
 - A safety helmet when welding above your head,
 - Safety shoes,
 - Safety goggles with sight glass of protection level 2 in compliance with the applicable standards and do not look directly into the electric arc.
- ◆ Remove all flammable materials and liquids from the vicinity of the work area before starting welding.
- ◆ Weld at a safe distance from flammable materials or liquids. Select a safety distance large enough to ensure that no danger can arise from weld spatter.



Protection of the stud welding unit

- ◆ Protect the stud welding machine against the ingress of foreign matter and liquids caused by cutting or grinding work in the vicinity of your work area.

This will help to prolong the service life of your stud welding machine.

Safety notices in accordance with EMF directive 2013/35/EU

Currents flowing through electrical conductors during stud welding cause electric and magnetic fields that can occur, in particular, near the hand-held welding guns, the welding arrangement (e.g., welding cables) and the welding power sources.

Due to the high currents, high EMF exposures may occur.



Danger for workers at particular risk within the meaning of the EMF directive

Persons at particular risk within the meaning of the EMF directive are:

- Workers with active implanted medical devices
- Workers with passive implanted medical devices that contain metal
- Workers with medical devices worn on the body
- Pregnant workers.

Strong electromagnetic fields are produced in the vicinity of the stud welding machine during welding.

To reduce the danger posed by electromagnetic fields, we recommend, among other things, the following rules of conduct:

- ◆ Lay all cables as close together as possible.

For proper bundling and safeguarding of the cables, HBS offers protective tubes in various sizes.

- ◆ Do not position yourself between the welding cables.
- ◆ Only lay the cables to one side and position them as far as possible from the operating personnel.
- ◆ Do not loop the cables over your body, especially not at head level.
- ◆ Completely unwind the welding cables.
- ◆ Use the shortest possible welding cables.
- ◆ Place portable welding power sources as far away as possible while welding.
- ◆ If possible, do not operate welding power sources in the immediate vicinity of other persons, do not sit directly next to the welding power source while working and do not lean against it.
- ◆ In addition to these safety notices, also observe your work instructions and accident prevention regulations.

2 Symbols and Terms Used

The symbols used in this operating manual have the following meanings:



Danger

Warns you of **hazards** that can lead to **injury of persons** or to **considerable material damage**.



Caution

Problems in operating **may occur** if this information is **not observed**.



No access for people with **active implanted cardiac devices**



No access for persons with **implants made of metal**



No access for **pregnant women**



Danger

Warns you of **electrical hazards**



Danger

Warns you of **electromagnetic fields** that can be generated during welding



These symbols prompt you to wear **personal protective clothing** when **working with the stud welding unit**.



This symbol prompts you to wear **ear protection**. A loud bang **> 90 dB (A)** can occur during the **welding process**.



Tip

Cross-reference to useful information on the use of the stud welding machine



Cross-references in this operating manual are marked with this symbol or *are printed in italics*



Fire hazard

Have a suitable fire extinguisher for the working area ready before starting work.



Work instruction



List




Glossary

Automatic welding head:	Device for welding of welding elements
Capacitor:	Component for storage of electrical energy.
Electric arc:	Autonomous gas discharge between two electrodes when the current is high enough. A whitish light is emitted in the process. The electric arc allows very high temperatures to be generated.
Rectifier:	Electrical component that converts alternating voltage into direct voltage
Stud feeder:	Device for automatic feeding of welding elements
Stud welding gun:	Device for welding of welding elements
Stud welding system:	Stud welding unit including stud welding gun or welding head
Stud welding unit:	Device for provision of the electrical energy for stud welding
Thyristor:	Electronic component for contact-free switching of high currents; switching takes place via the control input
Welding element:	Component such as stud or pin that is welded to the workpiece
Welding parameters:	Mechanical and electrical settings at the stud welding gun or welding head and at the stud welding unit (e.g. spring force, charging voltage)
Workpiece:	Components such as sheet metal or tubes to which the welding elements are to be fastened

3 Scope of Supply

The **basic configuration** of your stud welding gun with shielding gas leg assembly contains the following parts:

No. of pieces	Part	Type	Order No.
1	Stud welding gun cable length 4.80 m	A 12	93-20-274
1	Shielding gas leg assembly	PSS-2	93-40-021
1	Operating manual	A 12	E-BA 93-20-274



- ◆ Inspect the shipment for visible damage and completeness immediately on receipt.
- ◆ Report any transport damage or missing components immediately to the delivering shipping agent or the dealer (address, see page 2).

4 Accessories

For example:

Mounting tool set	93-40-116
Accessories ARC Gas	93-40-114
Protective hose, complete with zipper	80-11-430

Additional accessories can be found in our extensive accessories catalogue.



5 Technical Data


Stud welding gun type A 12 with shielding gas leg assembly
for ARC stud welding according to current standards

Complete welding range of the welding gun	M3 to M12, dia. 2 to 12 mm
Recommended welding range with this equipment	M6 to M12, dia. 6 to 12 mm
Stud length	10 to 120 mm
Stud material	Mild steel, stainless steel
Stud type	Any type or shape (special chucks if required)
Length compensation	3 mm automatic
Lift	Adjustment range 3 mm, lockable
Spring force	Adjustable, arresting
Welding cable	4.80 m, 35 mm ²
IP Code	IP 20 (protect against humidity)
Workplace noise level	Up to 90 dB (A) may occur during welding
Ambient temperature limits	0 °C to 40 °C
Dimension L x B x H	max. 400 x 65 x 140 mm (without cable, with shielding gas leg assembly) 200 x 65 x 140 mm (without cable, with tripod leg guidance)
Weight	3.7 kg (with cable, with shielding gas leg assembly) 3.0 kg (with cable, without shielding gas leg assembly)

Shielding gas leg assembly type PSS-2

for ARC stud welding with shielding gas according to current standards

Welding range	M6 to M12, dia. 6 to 12 mm
Dimension legs	8 x 220 mm
Dimension Shielding gas tube	L = 60 mm, D = 35 mm
Weight	0.750 kg





6 Intended Use

The stud welding gun has been designed exclusively for use with standardised stud welding elements. The use of any other elements will result in the desired strength of the welded joint being diminished.

The stud welding gun must only be connected to HBS stud welding units.

- ◆ Always check with the operating manual of your stud welding unit whether this stud welding gun may be used.

Observation of the operating manual of the stud welding unit being used is also part of the intended use.

7 Warranty

Please refer to the latest "General Terms and Conditions" for the scope of the warranty.


The warranty does not cover faults caused by e.g.

- Normal wear,
- Improper handling,
- Failure to observe the operating manual,
- Failure to observe the safety precautions,
- Use for other than the intended purpose, or
- Transport damage.

Warranty entitlement shall no longer be valid if modifications, changes or service and repair work is carried out by unauthorised persons or without the knowledge of the manufacturer. Invalidation of warranty entitlement shall also render the declaration of conformity invalid. The CE marking shall be declared invalid by the manufacturer.

We expressly point out that only spare parts and accessories or components approved by us may be used. The same applies likewise to installed units from our sub-suppliers.

8 Design and Function



The stud welding gun A 12 is equipped with an integrated length adjustment for automatic compensation of length tolerance for the welding elements.

The body of the stud welding gun consists of a sturdy two-part **plastic housing (2)**.

The **control cable** and the **welding cable (3)** are connected through the welding gun handle to the welding gun.

Positioned at the front of the stud welding gun are the welding piston and the **retaining nut (6)** used to fix the manual chuck.

At the front of the stud welding gun, the **tripod leg guidance (5)** is installed. Here the **shielding gas leg assembly type PSS-2** is mounted.

At the rear, there is the mechanism for **lift adjustment (8)**, rotating **graduated ring (7)** and for **spring force adjustment (1)**.

At the front of the welding gun handle, the **welding gun trigger (4)** is installed. It is used to trigger the welding process.

The stud welding gun is supplied with an **adaptor for ARC chucks (9)** (order no. 80-05-689).

The serial number is stamped on the welding gun handle.

Type plate

The type plate contains the following information:

- Manufacturer
- Type

9 Welding Process

This stud welding gun may only be used for drawn arc stud welding.

- ◆ Please refer to the original operating manual of the connected stud welding unit for the welding procedure.

10 Preparing the Stud Welding Gun

Prepare the stud welding gun by

- mounting the chuck
- adjusting lift and spring force
- adjusting the penetration depth (protrusion).




◆ Do not connect the stud welding gun to the stud welding unit **until it has been prepared.**

In this way you can avoid any unintentional starting of the welding process.

◆ Select a chuck suitable for your welding element:

**Welding elements for drawn arc stud welding
(shielding gas application):**

**Threaded studs with reduced shaft (RD)
Virtually fully-threaded studs (MD (DD))**



Stud dimension	Chuck	Depth for stud in mm
Ø d ₁		
M6	83-51-006	7
M8	83-51-008	9
M10	83-51-010	11
M12	83-51-012	13




Partially threaded studs (PD)



Stud dimension	Chuck	Depth for stud in mm
Ø d ₁		
M6	83-51-006	7
M8	83-51-008	9
M10	83-51-010	11
M12	83-51-012	13




Unthreaded studs (pins) (UD)



Stud dimension	Chuck	Depth for stud in mm
Ø d ₁		
6	83-51-006	7
8	83-51-008	9
10	83-51-010	11
12	83-51-012	13




Studs with internal thread (ID)



Stud dimension		Chuck	Depth for stud in mm
Ø d ₂	Ø d ₁		
10	M5	83-51-010	11
10	M6	83-51-010	11
12	M8	83-51-012	13




Threaded studs with flange (PS)



Stud dimension		Chuck	Depth for stud in mm
Ø d ₁	Ø d ₂		
M6	7	83-51-006	9
M8	9	83-51-008	11
M10	11	83-51-010	13




Unthreaded studs (pins) with flange (US)



Stud dimension		Chuck	Depth for stud in mm
Ø d ₁	Ø d ₂		
6	7	83-51-006	9
7.1	9	83-51-008	11
8	9	83-51-010	13



Studs with internal thread and flange (IS)




Stud dimension		Chuck	Depth for stud in mm
Ø d ₁	Ø D ₆		
6	M4	83-51-006	7
7.1	M5	83-51-071	9
8	M5	83-51-008	9
8	M6	83-51-008	9






10.1 Mounting the Chuck




ARC chuck




- 1 - Knurled cap screws
- 2 - Tripod leg

- ◆ Loosen the knurled cap screws (1).
- ◆ Pull the leg assembly off the stud welding gun.



- ◆ Screw the chuck onto the adaptor.




- ◆ Secure the adaptor with a 17 mm double open-ended wrench.
- ◆ Tighten the chuck with a 14 mm double open-ended wrench.



Damage through twisting

- ◆ **Never tighten the chuck if the adaptor is not held with a second double open-ended wrench!**

The interior units or the basic shell could otherwise twist and be damaged.



- 1 - Knurled cap screws
- 2 - Tripod leg





- ◆ Now attach the leg assembly to the stud welding gun.
- ◆ Clamp the tripod legs (2) with the knurled cap screws (1).

10.2 Setting the Welding Parameters

The insertion depth, lift and spring force are, among others, dependent on the workpiece and welding elements used and their diameters.

The specifications in the following table are guidelines.

- ◆ Select the applicable parameters for insertion depth, lift and spring force for your workpiece.




Welding elements Material: 4.8 (suitable for welding) / A2-50 ⁴⁾	Diameter of welding elements				ARC 800, ARC 1550, IT 50, IT 90, IT 130, IT 1002, IT 2002			
	metric ⁵⁾		imperial (US)		Stud welding gun parameter A 12 ¹⁾			
	Stud-diameter in mm	eff. diameter in mm	Stud-diameter in inches (approx.)	eff. diameter in inches (approx.)	Insertion depth P in mm	Lift ⁴⁾ L in mm	Spring force Scale	
Material of workpiece: Mild steel (suitable for welding) / stainless steel (suitable for welding) ⁴⁾								
	RD ²⁾	M6	4.7	1/4	0.185	2.0	1.0	6
	RD ²⁾	M8	6.2	5/16	0.244	2.0	1.0	6
	RD ²⁾	M10	7.9	3/8	0.311	2.5	1.2	6
	RD ²⁾	M12	9.5	1/2	0.374	3.0	1.4	6
		$\varnothing d_1$	$\varnothing d_2$	$\varnothing d_1$	$\varnothing d_2$			
	PD/MD (DD) ²⁾	M6	5.35	1/4	0.211	2.0	1.0	6
	PD/MD (DD) ²⁾	M8	7.19	5/16	0.283	2.5	1.2	6
	PD/MD (DD) ²⁾	M10	9.03	3/8	0.356	3.0	1.4	6
		$\varnothing d_1$		$\varnothing d_1$				
	UD ²⁾	6		1/4		2.0	1.0	6
	UD ²⁾	8		5/16		2.5	1.2	6
	UD ²⁾	10		3/8		3.0	1.4	6
		$\varnothing d_1$	$\varnothing d_2$	$\varnothing d_1$	$\varnothing d_2$			
	ID ²⁾	M5	10	#10 / 3/16	0.394	3.0	1.4	6
	ID ²⁾	M6	10	1/4	0.394	3.0	1.4	6
	ID ²⁾	M8	12	5/16	0.472	3.0	1.6	6

¹⁾ to be checked by test weldings

²⁾ Information and recommendations on this can be found in DIN EN ISO 14555.

⁴⁾ When welding on galvanized workpieces we recommend increasing the lift.

⁵⁾ according to EN ISO 13918

Welding elements Material: 4.8 (suitable for welding) / A2-50 ⁴⁾	Diameter of welding elements				ARC 800, ARC 1550, IT 50, IT 90, IT 130, IT 1002, IT 2002			
	metric ⁵⁾		imperial (US)		Stud welding gun parameter A 12 ¹⁾			
	Stud-diameter in mm	eff. diameter in mm	Stud-diameter in inches (approx.)	eff. diameter in inches (approx.)	Insertion depth P in mm	Lift ⁴⁾ L in mm	Spring force Scale	
Material of workpiece: Mild steel (suitable for welding) / stainless steel (suitable for welding) ⁴⁾								
		Ø d ₁	Ø d ₂	Ø d ₁	Ø d ₂			
	PS ³⁾	M6	7	1/4	0.276	2.5	1.6	6
	PS ³⁾	M8	9	5/16	0.354	2.5	2.0	6
	PS ³⁾	M10	11	3/8	0.433	2.5	2.4	6
		Ø d ₁	Ø d ₂	Ø d ₁	Ø d ₂			
	US ³⁾	6	7	1/4	9/32	2.5	1.6	6
	US ³⁾	7.1	9	9/32	3/8	2.5	2.0	6
	US ³⁾	8	9	5/16	3/8	2.5	2.0	6
		Ø d ₁	Ø D _g	Ø d ₁	Ø D _g			
	IS ³⁾	6	M4	1/4	5/32	2.5	1.6	6
	IS ³⁾	7.1	M5	9/32	#10 / 3/16	2.5	2.0	6
	IS ³⁾	8	M5	5/16	#10 / 3/16	2.5	2.0	6
	IS ³⁾	8	M6	5/16	1/4	2.5	2.0	6

- ¹⁾ to be checked by test weldings
- ²⁾ Information and recommendations on this can be found in DIN EN ISO 14555.
- ³⁾ Information and recommendations on this can be found in DVS 0902 and DVS 0904.
- ⁴⁾ When welding on galvanized workpieces we recommend increasing the lift.
- ⁵⁾ according to EN ISO 13918



The maximum adjustment values which can be set for the insertion depth (3.5 mm) as well as the lift (3 mm) should not be exceeded.




The specified values apply for welding in welding position PA.

Adjusting Lift



The adjustment piece for lift must not be turned by more than 360°.



- 1 - End ring
- 2 - Marking
- 3 - Adjustment piece lift
- 4 - Adjustment piece spring force

- ◆ Pull the adjustment piece for lift (3) to the rear out of the locking position.
- ◆ Turn the adjustment piece for lift to the selected lift (*see table under point 10.2*).

The lift can be adjusted in steps of 0.2 mm. (The empty space between 0 and 0.2 mm serves to mechanically balance out the lifting ring construction.)


- ◆ Now push the adjustment piece for lift forward again into the locking position.

Adjusting Spring Force



The adjustment piece for spring force must not be turned by more than 360°.

- ◆ Turn the adjustment piece for spring force only until you feel a noticeable resistance.
- ◆ Never turn the adjustment piece further with force, as otherwise mechanical parts of the stud welding gun may be damaged.



- 1 - End ring
- 2 - Marking
- 3 - Adjustment piece lift
- 4 - Adjustment piece spring force

- ◆ Turn the adjustment piece for spring force (4) up to the stop in „min“ direction. The position „0“ should be aligned with the marking (2) on the adjustment piece for lift (3).
- ◆ Now turn the adjustment piece for spring force to the selected value (see table under point 10.2).


You thus determine the insertion rate.



The scale on the adjustment piece for spring force does not correspond to any particular dimensions.


- ◆ You can **reduce** the insertion rate of the welding piston by turning the adjustment piece for spring force **clockwise** (direction „min“).
- ◆ You can **increase** the insertion rate of the welding piston by turning the adjustment piece for spring force **counter-clockwise** (direction „max“).

Setting the Insertion Depth (Protrusion)



- 1 - Knurled cap screws
- 5 - Welding element


◆ Place a welding element onto the chuck.



- 1 - Knurled cap screws

◆ Loosen the knurled cap screws.


Insertion depth X



- X - Insertion depth (Protrusion)

◆ Set the insertion depth (protrusion) (see table in 10.2).

◆ To do this, move the leg assembly.



- 1 - Knurled cap screws

◆ Clamp the tripod legs with the knurled cap screws (1).



11 Welding



- ◆ Work according to the *original operating manual of the HBS stud welding unit.*



Danger if used other than for the intended purpose

- ◆ Use the stud welding gun only for ARC stud welding and only in combination with stud welding units from manufacturer:



HBS Bolzenschweiss-Systeme GmbH & Co. KG
Felix-Wankel-Strasse 18
85221 Dachau
GERMANY



- ◆ Always check with the operating manual of your stud welding unit whether this stud welding gun may be used.

12 Troubleshooting






Danger from insufficiently qualified operating personnel

- ◆ Carry out only the work described here on your stud welding unit or stud welding gun.
- ◆ Repairs may only be carried out by appropriately qualified personnel.
- ◆ Inform your dealer or your maintenance department.

Fault	Possible cause	Fault localisation	Fault remedy	Performance
Welding elements not firmly attached	Wrong welding parameters selected	Check adjusted parameters on stud welding unit	Change adjusted parameters	Trained personnel
		Check spring force of stud welding gun	Change adjusted parameters	Trained personnel
	Insertion speed of welding element too low	Check lift of stud welding gun	Change adjusted parameters	Trained personnel
		Check welding piston and linear bearing for ease of movement *)	Clean or replace *)	Qualified specialists
Burning marks at the welding element	Chuck defective	Check chuck for possible defects	Replace chuck	Trained personnel
	Lamellas of chuck are not pretensioned	Check lamellas of chuck	Try to bend lamellas if possible, otherwise replace chuck	Trained personnel
		O-rings existing? Check o-rings for possible defects	Replace o-rings	Trained personnel
Stud welding gun does not weld	Control cable defective (no trigger signal available on stud welding unit)	Check control cable for electrical flow at control cable sleeve (Pin 3 and 4) with pressed welding gun trigger *)	In case of no flow: Replace control cable *)	Qualified specialists
		Check micro switch for electrical flow with pressed welding gun trigger *)	In case of no flow: Replace micro switch *)	Qualified specialists
	Welding current cable defective (no contact signal on stud welding unit)	Check, whether welding current cable is connected to stud welding unit in a technically correct way	Connect welding current cable	Trained personnel
		Check welding current cable for electrical flow *)	In case of no flow : Replace welding current cable and/or connecting cable *)	Qualified specialists



Fault	Possible cause	Fault localisation	Fault remedy	Performance
Stud welding gun does not weld	Ground connection defective (no contact signal on stud welding unit)	Check, whether ground cable is connected to workpiece in a technically correct way Check ground cable for electrical flow *)	Connect ground cable In case of no flow: Replace ground cable *)	Trained personnel Qualified specialists
	Stud welding unit defective	Follow the instructions of the connected stud welding unit	Repair required	Factory service or authorised agencies
Stud welding gun does not lift, in spite of  and 	Short circuit of magnetic circuit of the stud welding gun	Measure resistance value at control cable connector (18 Ω to 22 Ω) between Pin 1 and Pin 2 *)	Replace control cable connector, control cable and solenoid *)	Qualified specialists
	Solenoid defective	Measure solenoid (18 Ω to 22 Ω) *)	Replace solenoid *)	Qualified specialists
No  display	Magnetic circuit interrupted	Measure resistance value at control cable connector (18 Ω to 22 Ω) between Pin 1 and Pin 2 *)	Replace solenoid or control cable *)	Qualified specialists



Work marked with *) may only be carried out by qualified electricians!

- ◆ Please contact our Service department if none of the measures described remedies the situation.
- ◆ Please use the form „Service & Support“ in the annex to send in the stud welding gun.

13 Maintenance and Care



Electric shock hazard

- ◆ Never perform maintenance and service work on your stud welding gun while it is connected to the stud welding unit
- ◆ Prior to this disconnect the stud welding gun from the stud welding unit.



Danger from insufficiently qualified operating personnel

- ◆ Carry out only the work described here on your stud welding gun.
- ◆ Repairs may only be carried out by appropriately qualified personnel.
- ◆ Inform your dealer or your maintenance department.

13.1 Cleaning

- ◆ Clean the casing of your stud welding gun with a slightly damp washcloth, when necessary.



- ◆ **Do not use solvents for cleaning.**

These may damage plastic components.



13.2 Inspection and Tests

- ◆ Inspect the chuck before every use.
- ◆ Replace the chuck if you discover burning marks on the welding element and/or on the chuck.
- ◆ Work here in accordance with *point 13.3 „Changing the Chuck“* in this manual.
- ◆ Before every use, inspect the bellows on the front part of the stud welding gun for proper seating and/or damage.




- ◆ **Never work with damaged or incorrectly seated bellows.**

This will contribute to a long service life of your stud welding gun.

- ◆ Inform your dealer or maintenance department if you discover any damage.


- ◆ Before every use, check that the type designations and adjustment aids on the stud welding gun are still legible.
- ◆ Clean the type plates in the event of soiling.
- ◆ Replace any type plates that are damaged or no longer legible.

13.3 Changing the Chuck




- 1 - Knurled cap screws
- 2 - Tripod leg


- ◆ Loosen the knurled cap screws (1).
- ◆ Now remove the leg assembly from the stud welding gun.




- ◆ Unscrew the chuck from the adaptor.



- ◆ Loosen the retaining nut with a 17 mm double open-ended wrench.
- ◆ You thereby simultaneously loosen the chuck adaptor.
- ◆ Check the chuck adaptor for burning marks.
- ◆ Replace the chuck adaptor if necessary.
- ◆ Tighten the retaining nut again with the 17 mm double open-ended wrench.
- ◆ You thereby simultaneously tighten the chuck adaptor.



- ◆ Screw the new chuck onto the adaptor.




- ◆ Secure the adaptor with a 17 mm double open-ended wrench.
- ◆ Tighten the chuck with a 14 mm double open-ended wrench.



Damage through twisting

- ◆ **Never tighten the chuck if the adaptor is not held with a second double open-ended wrench!**

The interior units or the basic shell could otherwise twist and be damaged.



- 1 - Knurled cap screws
- 2 - Tripod leg

- ◆ Now attach the leg assembly to the stud welding gun.
- ◆ Clamp the tripod legs (2) with the knurled cap screws (1).

14 Storage

- ◆ Store the stud welding gun in a safe and dust-free location when not in use.
- ◆ Protect the stud welding gun from moisture and metallic contamination.



- ◆ Store the stud welding gun only under the following ambient conditions.

Storage temperature:


-5 °C to +50 °C (23 °F to 122 °F)

Relative humidity:

0 % - 50 % at +40 °C (104 °F)

0 % - 90 % at +20 °C (68 °F)

15 Disposal



- ◆ Dispose of the stud welding gun only via the manufacturer or a specialist disposal company.
- ◆ Never dispose of the stud welding gun in the domestic refuse.



Declaration of Incorporation of partly completed Machinery

to Directive 2006/42/EC, Annex II 1 B
(Original Declaration of Incorporation)

Herewith the manufacturer

HBS Bolzenschweiss-Systeme GmbH & Co. KG
Felix-Wankel-Strasse 18
P.O. Box 13 46
85221 Dachau
GERMANY
Phone +49 8131 511-0
Fax +49 8131 511-100

declares for the following product

Machine information: Stud welding gun with shielding gas leg assembly PSS-2
Type: A 12
Order No: 93-20-274
Serial No: 93-20-274/212XXXX
Year of manufacture: 2021

that the following essential requirements of the above mentioned Directive – including changes to the Directive to be applied at the moment of this declaration – were applied and fulfilled:

Annex I, Article 1, 1.1.2, 1.1.3, 1.1.5, 1.1.6, 1.1.7, 1.2.1, 1.2.2, 1.2.3, 1.2.4.1, 1.2.6, 1.3.1, 1.3.2, 1.3.3, 1.3.4, 1.3.7, 1.3.8, 1.3.9, 1.4.1, 1.4.2.1, 1.5.1, 1.5.2, 1.5.4, 1.5.5, 1.5.6, 1.5.8, 1.5.10, 1.5.11, 1.5.15, 1.5.16, 1.6.1, 1.6.2, 1.6.3, 1.6.4, 1.7.1.1, 1.7.2, 1.7.3, 1.7.4,

that special technical documentation was compiled in accordance with Part B of Annex VII of the above mentioned regulation and will be transmitted, in response to a reasoned request by the national authorities as follows:

The above mentioned documents will be transmitted by e-mail as a data file in German language.

that this partly completed machinery must not be put into service until the final machinery into which it is to be incorporated has been declared in conformity with the provisions of the Directive, where appropriate.

that this incomplete machine complies with corresponding regulations of the following additional EU Directives, including any changes to be applied at the moment of this declaration:

„Electromagnetic compatibility“ 2014/30/EU


Protection targets of the low voltage regulation were kept to appendix I, no. 1.5.1 of the machine regulation.

Persons who are based in the European community and who are authorised to compile the technical documentation:

Name: Heike Otto Address: see manufacturer

Dachau, 04.01.2021

Place of issue, Date



Gregor Gröger (CEO/HBS)



Service & Support

With the return please attach a copy of the filled out form together with the repair number given by HBS! Repairs without repair number will not be processed.

Repair number

(given by HBS)

Company:

Name / Surname:

Street:

City, State and ZIP/Postcode:

Country:

Phone & Fax:

E-mail address:

Stud welding unit / stud welding gun
type of model:

Serial number:

Date of purchase:

Purchased at distributor:

Detailed descriptions of errors:

Service & Support may be done up to the value of EUR _____
without quotation:

Yes

No

Could you find any damage / burn marks

on the cables:

Yes

No

on chucks:

Yes

No

Are all plug and screw connections tightly fastened *:

Yes

No

Are there any burn marks on plug or screw connections:

Yes

No

Is there any other visual damage (e.g. cracks, dents):

Yes

No

Have you checked the fuses:

Yes

No

Default on the display of the stud welding unit:

ARC / IT					CD / CDM / SC					

Which LED's are illuminated (please mark with a cross)?

Please e-mail or fax this form to service@hbs-info.de or fax: +49 8131 511-100.
In case a repair is necessary a repair number will be given!

* See also operating manual chapter „Connection“
** Doesn't light when using a contact welding gun



Index

A

accessories	13
adjusting lift	25
adjusting spring force	26
adjustment piece for lift	25
adjustment piece for spring force	26
airborne particulates	7
automatic welding head	12

B

bang	8
basic configuration	13

C

capacitor	12
changing the chuck	33
chuck adaptor	33
cleaning	31
clothing, non-flammable	8
control cable	18

D

danger from incorrect use	6
Declaration of Incorporation	36
disposal	35

E

ear protection	10
electrical hazards	10
electric arc	12
electromagnetic fields	10
EMF directive, safety notices	9

F

fire extinguisher	8
fire hazard	8
form „Service & Support“	30, 37
full-ear hearing protection	8
fumes, harmful to health	7

G

glossary	12
goggles with visor	8
graduated ring	18

H

hazards for the machine	10
hazards for the operator	10

heart pacemaker	7, 10
helmet	8

I

insertion depth	23
intended use	16, 28

L

lift	23
lift adjustment	18

M

maintenance and care	31
mounting the chuck	22

O

operating manual	13
------------------------	----

P

protective apron	8
protective equipment	8
protective equipment, personal	10
protective gloves	8

R

rectifier	12
retaining nut	18

S

safety goggles	10
safety goggles with sight glass	8
safety precautions	6
scope of supply	13
serial number	18
setting the insertion depth	27
shielding gas leg assembly	18
spring force	23
spring force adjustment	18
storage	35
storage temperature	35
stud feeder	12
stud welding gun	12
stud welding system	12
stud welding unit	12
symbols used	10

T

tripod leg guidance	18
troubleshooting	29



type plate 18

W

warranty entitlement 17
welding cable 18
welding element 12, 16
welding gun, design 18
welding gun trigger 18
welding parameters 12, 23
workpiece 12





HBS Bolzenschweiss-Systeme GmbH & Co. KG
Felix-Wankel-Strasse 18 • 85221 DACHAU • GERMANY
Phone +49 8131 511-0 • Fax +49 8131 511-100 • E-mail international@hbs-info.com

www.hbs-info.com